

Ako naprogramovať diaľkového ovládača VU+ pre ovládanie TV

BLAUPUNKT	10723, 10599, 10256, 10253, 10119, 10099, 10097,10096, 10092, 10091
BLUSENS	10787, 10654, 10611
BLUE SKY	10286, 10282, 10273, 10264, 10250, 10249, 10172, 10109
BLUESTAR	10108, 10063
BOMANN	10282
BONDSTEC	10163
BRANDT	10270, 10195, 10193
BRIONVEGA	10204
BROKSONIC	10285
BRUNS	10204
BUSH	10774, 10766, 10725, 10568, 10314, 10303, 10287, 10286, 10283, 10264, 10250, 10249, 10232, 10202, 10123, 10121, 10115, 10108, 10074, 10069, 10063, 10031
CAMPER	10085
CELLO	10536, 10434, 10318, 10315, 10312, 10311, 10310, 10301
CENTURY	10204, 10165
CGE	10267, 10260, 10165
CGM	10264, 10108, 10086, 10085
CHANGHONG	10717
CIE	10171, 10170, 10166, 10108, 10064, 10025
CINERAL	10272
CINEX	10294, 10031
CLARIVOX	10258, 10232
CLATRONIC	10742, 10296, 10294, 10286, 10282, 10267, 10260, 10255, 10250, 10249, 10218, 10185, 10171, 10165, 10164, 10110, 10108, 10074, 10064
CMX	10770, 10765, 10763, 10591, 10589
CONDOR	10267, 10260, 10255, 10229, 10171, 10109, 10108
CONIC	10219
CONRAC	10225
CONTEC	10277, 10171
CONTI	10263, 10250
CONTINENTAL	10172
CONTINENTAL EDISON	10193, 10172
COSMOS	10108
CROSLEY	10267, 10204, 10165
CROWN	10764, 10286, 10282, 10274, 10267, 10264, 10263, 10255, 10250, 10249, 10185, 10171, 10108, 10090, 10086, 10085,10063
CS-ELECTRONICS	10163, 10064
CURTIS	10260, 10111
D-VISION	10108
DAEWOO	10720, 10598, 10540, 10519,10431, 10269, 10170, 10127, 10120, 10108
DANSAI	10219
DANTAX	10250, 10074
DAYTEK	10194
DECCA	10190, 10189, 10184, 10128, 10108, 10069, 10066, 10063
DELTON	10249
DENVER	10703, 10638, 10625, 10596, 10282, 10171, 10074
DESMET	10108

DGM	10669, 10426
DIBOSS	10621
DIGIFUSION	10225
DIGINUM	10031
DIGITREX	10586
DIGIX	10187
DISNEY	10062
DMTECH	10778, 10529, 10320,10308, 10304, 10286, 10249
DOMUS	10108
DUAL	10293, 10286, 10279, 10250, 10249, 10248, 10233, 10127, 10123, 10108
DUMONT	10267, 10234, 10204, 10185, 10110, 10109, 10105, 10102, 10087
DURABRAND	10282, 10249
DYON	10754, 10666, 10664, 10618,10610
E-MAX	10194
ECG	10751, 10250, 10117, 10069
EDISON	10172
EDISON MINERVA	10172
ELBE	10273, 10229, 10209, 10185, 10120, 10108, 10074, 10058
ELBIT	10248, 10108
ELCIT	10164
ELECTRIC	10109
ELECTRIC CO	10250
ELEKTA	10171, 10108
ELEKTRONIKA	10274, 10116, 10108, 10086
ELEMIS	10294, 10282, 10074, 10031
ELIN	10108, 10087
ELITE	10467, 10064
ELMAN	10185
ELTA	10171, 10108
EMERSON	10204, 10108, 10086
ESC	10108
EUROLINE	10286
EUROPHON	10185, 10033
EUROSKY	10249
EVELUX	10116, 10108
EXPERT (1)	10089
EXQUISIT	10110, 10108
FENNER	10251, 10249, 10171, 10108
FERGUSON	10594, 10549, 10548, 10544, 10507, 10270, 10195, 10078, 10032
FIDELIS	10108
FINLANDIA	10195, 10189, 10105, 10104, 10033
FINLUX	10290, 10279, 10276, 10275, 10251, 10234, 10229, 10225, 10189, 10128, 10116, 10108, 10107, 10105, 10104, 10103, 10102, 10087, 10074, 10069, 10066, 10031
FIRST-LINE	10294, 10273, 10264, 10251, 10249, 10108
FISHER	10233, 10221, 10086, 10052, 10051
FLINT	10273
FORCE	10286, 10194, 10123
FORMENTI	10229, 10110, 10109, 10108
FRABA	10248, 10108

FRONTECH	10220, 10171, 10166
FUJITSU GENERAL	10554, 10197, 10088
FUNAI	10755, 10629, 10617, 10293, 10286, 10264, 10249
F&U	10555
GALAXIS	10260, 10255, 10185, 10108
GALAXY	10255
GALERIA	10171
GBC	10269, 10267, 10171
GEC	10189
GELOSO	10171, 10164, 10064
GENERAL	10171
GENERAL TECHNIC	10171
GERICOM	10300, 10225, 10187
GOLDFUNK	10264, 10249
GOLDHAND	10171
GOLDLINE	10273
GOLDSTAR	10288, 10268, 10263, 10250, 10237, 10219, 10191, 10171, 10166, 10163, 10110, 10108, 10090, 10074, 10038
GOODING	10172
GOODMANS	10605, 10543, 10321, 10316, 10306, 10305, 10287, 10286, 10285, 10275, 10270, 10269, 10268, 10264, 10251, 10250, 10249, 10225, 10224, 10195, 10194, 10187, 10176, 10171, 10170, 10123, 10120, 10115, 10110, 10109, 10108, 10103, 10074, 10068, 10064, 10063, 10031
GORENJE	10286, 10274, 10249, 10116, 10108, 10090, 10086
GPM	10064
GRADIENTE	10038
GRAETZ	10296, 10263, 10250, 10249, 10172, 10108
GRAN PRIX	10734, 10696, 10294, 10127, 10031
GRANADA	10270, 10251, 10224, 10218, 10208, 10195, 10189, 10184, 10167, 10128, 10119, 10111, 10109, 10108, 10105, 10104, 10103, 10090, 10086, 10085, 10082, 10081, 10079, 10078, 10075, 10054, 10051, 10049, 10045, 10043, 10042, 10041, 10039, 10036, 10033, 10032, 10029, 10027, 10022
GRANDIN	10273, 10069
GREAT WALL	10074
GRUNDIG	10790, 10789, 10777, 10691, 10690, 10552, 10527, 10510, 10287, 10253, 10250, 10232, 10210, 10202, 10194, 10187, 10172, 10155, 10130, 10117, 10116, 10101, 10100, 10097, 10096, 10095, 10094, 10093, 10092, 10091, 10073, 10069, 10063, 10031
GRUNKEL	10785, 10732, 10545
H&E	10282
HAIER	10774, 10733, 10313
HANNSPREE	10706, 10602
HANSEATIC	10308, 10296, 10277, 10269, 10251, 10250, 10248, 10229, 10225, 10220, 10191, 10171, 10127, 10120, 10110, 10108, 10100, 10085, 10060
HARWA	10297
HB	10282
HB INGELEN	10172
HCM	10277, 10171, 10108
HINARI	10224, 10171, 10108, 10064
HISAWA	10273
HISENSE	10772, 10753, 10752, 10551, 10302
HIT	10204

HITACHI	10744, 10659, 10581, 10515, 10422, 10295, 10286, 10279, 10276, 10269, 10266, 10249, 10219, 10193, 10189, 10186, 10143, 10128, 10127, 10123, 10120, 10119, 10108, 10104, 10057, 10056, 10055, 10054, 10053, 10041, 10040, 10039, 10035, 10030, 10029, 10028, 10024, 10023, 10022
HITSU	10273
HL	10251, 10195, 10108
HOHER	10250, 10249, 10123, 10117, 10069
HOSHAI	10264
HUMAX	10776, 10577, 10576
HYPER	10171, 10163
HYPSON	10293, 10264, 10263, 10250, 10249, 10118, 10108, 10074, 10069, 10063
HYUNDAI	10317, 10235, 10180, 10155, 10152
ICE	10171, 10108, 10064
IDEAL	10264
IMPERIAL	10267, 10260, 10255, 10229, 10165, 10110, 10109, 10108
INGELEN	10279, 10273
INGERSOLL	10171
INNO HIT	10249, 10237, 10189, 10127
INTERCORD	10233
INTERFUNK	10265, 10255, 10251, 10165, 10108, 10067
INTERVISION	10191, 10166, 10108, 10086, 10085
IPOSTAR	10171
IRRADIO	10264, 10249, 10237, 10163, 10108, 10074
IRT	10446, 10440, 10439, 10437
ISKRA	10085
ITL	10171
ITS	10171, 10064
ITT	10784, 10268, 10250, 10117, 10032, 10031
I-JOY	10667
JAY-TECH	10761
JETPOINT	10268
JMB	10063
JOCEL	10283, 10282, 10074, 10069
JTC	10761
JVC	10604, 10588, 10575, 10278, 10169, 10120
KAISUI	10280, 10273, 10249, 10127
KAMACROWN	10064
KAPSCH	10197, 10089
KARCHER	10289, 10282, 10274, 10273, 10250, 10185, 10117, 10109, 10108, 10074, 10031
KATHREIN	10187
KENDO	10296, 10273, 10270, 10249, 10229, 10127, 10108, 10060
KENNEDY	10197
KENNEX	10264, 10249, 10108
KEYMAT	10235, 10207
KIOTO	10442, 10441, 10439, 10438, 10436
KITON	10293, 10264, 10249
KNEISSEL	10273, 10264, 10249, 10229, 10108, 10058
KOERTING	10274, 10204, 10086

KOGAN	10758
KUBA ELECTRONIC	10233
LAZER	10074
LECSO	10116
LENCO	10721, 10689, 10684, 10682, 10628, 10593, 10546, 10249, 10170, 10110, 10108
LENOIR	10264, 10249
LEVEL	10612, 10425
LG	10708, 10707, 10634, 10592, 10553, 10512, 10511, 10509, 10504, 10503, 10502, 10501, 10288, 10286, 10283, 10263, 10250, 10181, 10110, 10108, 10090, 10069, 10038, 10015, 10014, 10013
LIESENKOETTER	10108
LIFETEC	10293, 10264, 10249, 10171, 10170, 10127, 10118, 10108, 10074, 10064
LOEWE	10608, 10204, 10142, 10138, 10131
LOGIK	10757, 10680, 10649, 10630, 10606, 10587, 10264, 10187, 10070
LUMA	10249, 10229, 10197
LUMATRON	10249, 10229
LUXOR	10279, 10276, 10275, 10267, 10251, 10249, 10237, 10186, 10128, 10116, 10105, 10104, 10103, 10074, 10066, 10032
M ELECTRONIC	10276, 10127, 10120, 10105, 10104, 10103
M.D.C.	10074
MACROLUX	10069
MAGNADYNE	10204, 10185, 10164, 10163, 10108
MAGNAFON	10185
MAGNASONIC	10108
MAGNAVOX	10251
MAGNUM	10294, 10263, 10250, 10074, 10031
MANHATTAN	10264, 10249
MARANTZ	10108
MARSHAL	10064
MASCOM	10279, 10074, 10031
MASTERS	10108
MATSUI	10587, 10250, 10249, 10202, 10196, 10172, 10171, 10116, 10108, 10100, 10096, 10074, 10070, 10069, 10063, 10062, 10060, 10051, 10032, 10025
MAXELL	10249
MAXIM	10031
MEDION	10788, 10779, 10771, 10745, 10722, 10699, 10683, 10605, 10570, 10293, 10287, 10283, 10279, 10264, 10251, 10250, 10249, 10225, 10194, 10187, 10127, 10110, 10108, 10074, 10031
MEGAS	10273
MEMORY	10286
METEOR	10185
METZ	10736, 10265, 10264, 10254, 10249, 10219, 10108, 10101, 10100, 10097, 10096, 10092, 10074
MICROMAXX	10293, 10282, 10264, 10250, 10249, 10074
MIKOMI	10516, 10286
MINERVA	10232, 10172, 10100, 10097, 10092
MIRAI	10582
MITSAI	10110
MITSUBISHI	10249, 10224, 10204, 10120, 10119, 10097, 10077, 10076, 10075, 10071
MIVAR	10781, 10267, 10262, 10259, 10223, 10209

MMC2	10003, 10002, 10001
MORAVA	10249, 10152, 10109
MOSAIC	10264, 10249
MT LOGIC	10773, 10718, 10590, 10250
MTC	10131, 10086
MULTITEC	10264, 10249
MULTITECH	10267, 10185, 10171, 10108, 10090, 10085, 10031
MURPHY	10536, 10232
MURYUANA	10251
NAKIMURA	10170
NECKERMANN	10274, 10256, 10255, 10251, 10250, 10233, 10217, 10216, 10212, 10211, 10204, 10169, 10143, 10119, 10118, 10108, 10101, 10100, 10096, 10093, 10092, 10084, 10074, 10060, 10059, 10043, 10037
NEI	10108, 10064
NEUFUNK	10250, 10249, 10109
NEX	10448
NEXIUS	10282
NIKE	10108
NIKKAI	10219
NIKKEI	10264, 10249
NIKKO	10108
NISSAN	10268
NOBLIKO	10267, 10232, 10185
NOKIA	10719, 10653, 10645, 10279, 10276, 10275, 10251, 10106, 10105, 10104, 10103, 10102, 10074, 10032
NORDMENDE	10657, 10518, 10296, 10282, 10270, 10261, 10249, 10195, 10193, 10069
NORM N	10108
NORTEK	10264, 10249
NOVA	10087
NOVATRONIC	10108
OCEANIC	10276, 10104, 10103, 10032
ODYS	10782, 10727, 10697, 10677, 10674, 10656, 10647, 10642, 10633, 10632, 10610, 10566, 10526, 10525, 10519
OKANO	10255, 10108
ONWA	10280, 10108, 10064
OPERA	10250
ORAVA	10150, 10108, 10098, 10090
ORBITER	10086
ORION	10760, 10675, 10665, 10662, 10660, 10515, 10507, 10296, 10251, 10250, 10249, 10236, 10219, 10205, 10202, 10196, 10194, 10187, 10185, 10118, 10108, 10074, 10070, 10069, 10064, 10063, 10062, 10060, 10059, 10025
ORION (H)	10249, 10228, 10116, 10108, 10074, 10062
ORMOND	10249
OSAKI	10108
OTAKE	10196, 10060, 10059
OTF	10282, 10204, 10108, 10090
OTTO-VERSAND	10277, 10270, 10269, 10251, 10250, 10233, 10230, 10217, 10216, 10213, 10212, 10211, 10205, 10202, 10195, 10193, 10185, 10171, 10168, 10167, 10163, 10152, 10143, 10131, 10127, 10119, 10118, 10116, 10111, 10110, 10108, 10101, 10100, 10097, 10096, 10093, 10092, 10084, 10083, 10082, 10081, 10074, 10069, 10063, 10060, 10059, 10040, 10036, 10027, 10026

OVP	10108, 10098, 10090
PACIFIC	10250, 10249, 10236, 10109, 10063
PALLADIUM	10293, 10276, 10260, 10255, 10250, 10249, 10229, 10171, 10165, 10143, 10127, 10118, 10108, 10031
PANASONIC	10639, 10740, 10595, 10508, 10254, 10168, 10167
PEAQ	10716, 10668
PHILCO	10267, 10260, 10255, 10204, 10165, 10108
PHILIPS	10735, 10710, 10700, 10678, 10650, 10635, 10631, 10627, 10626, 10580, 10539, 10534, 10251, 10230, 10122, 10119, 10116, 10112, 10111, 10109, 10108, 10092, 10069, 10067, 10065, 10021, 10020, 10019, 10009, 10008, 10007
PHOCUS	10250, 10225, 10130, 10117
PHOENIX	10110, 10108, 10090
PIONEER	10193, 10108
PIONIER	10090
PLAYSONIC	10250, 10090
POWERPOINT	10172
PRANDONI	10069, 10066
PREMIER	10069
PRIMA	10219
PRIME	10697, 10249
PRIMUS	10251
PRO 2	10031
PROFEX	10267, 10171
PROFILO	10294, 10108, 10074, 10031
PROFITRONIC	10185, 10108
PROLINE	10286, 10285, 10270, 10269, 10249, 10229, 10205, 10189, 10128, 10120, 10109
PROSONIC	10637, 10636, 10625
PROTECH	10264, 10249, 10219, 10108, 10074
PROVISION	10282, 10120, 10109, 10108, 10066
PYE	10251, 10109, 10108
QMEDIA	10775, 10737, 10728, 10676
QUADRO	10293, 10286, 10249, 10123
QUELLE	10261, 10257, 10255, 10251, 10237, 10234, 10232, 10229, 10221, 10219, 10218, 10217, 10216, 10213, 10212, 10211, 10205, 10204, 10197, 10195, 10185, 10171, 10169, 10168, 10167, 10165, 10163, 10142, 10131, 10119, 10118, 10116, 10112, 10111, 10108, 10105, 10102, 10101, 10100, 10097, 10096, 10092, 10090, 10088, 10087, 10086, 10074, 10072, 10060, 10059, 10043, 10042, 10040, 10036, 10027, 10025
RADIOLA	10251, 10108, 10067, 10065
RADIOMARELLI	10164, 10108
RADIONETTE	10181
RADIOTONE	10294, 10249, 10171, 10108, 10085, 10074
RANK	10232
RECCO	10441
RECOR	10249, 10108
REDSTAR	10282
REFLEX	10293, 10264, 10249, 10108
REFLEXION	10596
REOC	10250
REVOX	10131
REX	10197, 10164, 10089, 10088

RFT	10204, 10116, 10085, 10064
RM 2000	10264, 10249, 10108
ROADSTAR	10286, 10280, 10264, 10263,10251, 10250, 10249,10117, 10108, 10090, 10069, 10063
ROBOTRON	10204
ROSITA	10171
ROWA	10283, 10249
ROYAL	10277
ROYAL LUX	10282
SABA	10270, 10249, 10195, 10193, 10074
SAGEM	10273, 10206
SAISHO	10205, 10070, 10069, 10060, 10025
SAKIO	10171
SALORA	10767, 10751, 10687, 10590, 10535, 10279, 10276, 10275, 10251, 10249, 10237, 10143, 10128, 10116, 10105, 10104, 10103, 10074, 10066, 10032
SAMBERS	10267, 10185
SAMSUNG	10743, 10738, 10712, 10693, 10692, 10607, 10601, 10550, 10514, 10506, 10505, 10284, 10268, 10257, 10237, 10220, 10171, 10126, 10108, 10086, 10045
SANKYO	10108
SANSUI	10264, 10249, 10108
SANY	10193
SANYO	10286, 10249, 10221, 10218, 10189, 10123, 10108, 10087, 10086, 10074, 10052, 10051, 10033, 10032, 10032
SCHAUB LORENZ	10537, 10531, 10296, 10277, 10275, 10264, 10250, 10249, 10171, 10117, 10116, 10108, 10074
SCHNEIDER	10702, 10621, 10324, 10282, 10269, 10264, 10251, 10250, 10249, 10233, 10163, 10152, 10127, 10116, 10108, 10088, 10069, 10064, 10063
SCHNEIDER (F)	10251, 10067, 10065
SCOTT	10648, 10638, 10593
SEELVER	10069
SEG	10756, 10747, 10655, 10573, 10560, 10559, 10517, 10293, 10286, 10269, 10267, 10264, 10249, 10219, 10185, 10171, 10165, 10123, 10115, 10108, 10064
SEITECH	10282
SELECO	10251, 10249, 10229, 10226, 10197, 10195, 10110, 10109, 10089, 10088
SELECT	10264
SENCOR	10117
SENTRA	10064, 10049
SERINO	10273
SET	10074
SHARP	10646, 10749, 10748, 10714, 10644, 10568, 10567, 10558, 10557, 10556, 10432, 10423, 10224, 10171, 10084, 10083, 10082, 10081, 10073
SHINTOM	10249, 10108
SHINTOSHI	10108
SHIVAKI	10264, 10249, 10108
SIAREM	10204, 10185
SIEMENS	10554, 10294, 10256, 10221, 10219, 10218, 10101, 10100, 10097, 10096, 10093, 10092, 10074
SI ERA	10069
SILVA SCHNEIDER	10597, 10294, 10286, 10282, 10074, 10031
SILVER	10277, 10224, 10171, 10074, 10064
SILVERCREST	10780

SIM2	10226
SINGER	10251, 10204, 10185, 10164, 10108, 10069
SINUDYNE	10282, 10251, 10249, 10212, 10204, 10196, 10185, 10118, 10074, 10069, 10063, 10062, 10025
SKY	10207, 10194, 10187
SLX	10264
SMARAGD	10172
SONIX	10194
SONOKO	10249
SONTEC	10108
SONY	10739, 10538, 10217, 10216, 10215, 10214, 10213, 10212, 10211, 10072
SOUNDCOLOR	10264, 10249, 10108, 10074
SOXO	10545
SPECTRA	10170
STANDARD	10108
STARLITE	10264, 10171, 10108
STARLUX	10171
STARS	10251
STERN	10229, 10197, 10089, 10088
STRONG	10286, 10123, 10115
SUNGOO	10672
SUNKAI	10273
SUNSTAR	10171, 10108, 10074
SUNSTECH	10783, 10671
SUPERIOR	10286
SUPERTECH	10249, 10171, 10108, 10074
SUPRATECH	10670, 10620, 10619
SUPREMA	10273
SWISSTEC	10704, 10603, 10574, 10309, 10207, 10194, 10187
TADISTAR	10108
TANDBERG	10254
TASHIKO	10224, 10218
TATUNG	10286, 10282, 10189, 10184, 10128, 10118, 10108, 10079, 10070, 10069, 1066, 10063
TAURAS	10762, 10282
TCL	10716, 10668, 10565, 10564, 10563, 10562, 10561, 10152
TCM	10127
TD DESIGN	10131
TEAC	10661
TEC	10264, 10249, 10171, 10170, 10166, 10165, 10108
TECHLINE	10293, 10264, 10249, 10185, 10123, 10108
TECHNICA	10286, 10282, 10249
TECHNIKA	10715, 10600, 10585, 10584, 10547
TECHNISAT	10695, 10694, 10571, 10248, 10118, 10108
TECHWOOD	10249, 10123, 10115
TECNIMAGEN	10251, 10069
TECNISON	10249, 10171, 10108
TECSONIC	10249
TEKON	10268, 10171
TELEFUNKEN	10688, 10679, 10530, 10270, 10261, 10225, 10195, 10193

TELEOPTA	10171
TELERENT	10233, 10131
TELESTAR	10294, 10282, 10227, 10108, 10074, 10031
TELETECH	10264, 10249, 10171, 10165, 10108
TELETON	10197, 10089, 10088
TELEVIEW	10031
TELRA	10294, 10108, 10074, 10031
TENSAI	10264, 10249, 10191, 10171, 10127, 10120, 10110, 10108, 10064
TENSON	10171
TESLA	10282, 10273, 10264, 10263, 10250, 10249, 10229, 10204, 10150, 10127, 10116, 10109, 10108, 10090, 10074, 10069
TEVION	10771, 10583, 10294, 10287, 10264, 10250, 10249, 10225, 10127
THOMSON	10716, 10668, 10565, 10564, 10563, 10562, 10561, 10270, 10261, 10195, 10193
THOMSON IR2000	10006, 10005, 10004
THOMSON REC 80	10012, 10011, 10010
THORN	10270, 10251, 10232, 10224, 10216, 10213, 10211, 10195, 10189, 10188, 10170, 10169, 10168, 10128, 10120, 10116, 10110, 10108, 10107, 10106, 10105, 10102, 10097, 10087, 10079, 10078, 10075, 10072, 10067, 10065, 10052, 10049, 10045, 10043, 10036, 10033, 10032, 10028, 10026
THORN-FERGUSON	10195, 10188
TOBO	10171
TOKYO	10268
TOPLINE	10264, 10249
TOPVISION	10085
TOSHIBA	10663, 10769, 10768, 10729, 10711, 10616, 10615, 10614, 10613, 10523, 10522, 10520, 10284, 10268, 10250, 10249, 10232, 10208, 10203, 10202, 10100, 10092, 10063, 10050, 10049, 10048, 10047, 10045, 10043, 10042, 10037, 10036, 10027, 10026
TOSUMI	10250
TOWADA	10185
TRANS-CONTINENTS	10069
TRILUX	10292, 10264, 10120
TRISTAR	10064
TRIUMPH	10234, 10219, 10025
TVE	10249
TWF	10320
UHER	10249, 10233, 10197, 10185, 10131, 10108, 10089
ULTRAVOX	10204, 10185, 10164, 10108
UMC	10723, 10715, 10704, 10661, 10609, 10606, 10603, 10600, 10599, 10585, 10584, 10579, 10547, 10528
UNIMOR	10086, 10085
UNITED	10705, 10610, 10596, 10286, 10282, 10263, 10250, 10170, 10108, 10090, 10063
UNIVERSUM	10293, 10286, 10279, 10276, 10275, 10274, 10270, 10264, 10260, 10249, 10237, 10234, 10229, 10227, 10219, 10218, 10171, 10123, 10116, 10109, 10108, 10105, 10104, 10103, 10102, 10100, 10097, 10087, 10086, 10074, 10025
UNIVOX	10204
VESTEL	10701, 10513, 10303, 10293, 10286, 10264, 10249, 10123, 10121, 10115, 10108
VESTL	10433
VIDEOCON	10658, 10657, 10651, 10424
VIDEOSAT	10165
VIDEOSEVEN	10194, 10187

VIDEOTON	10249, 10193
VIEWSON	10450, 10449, 10447, 10445, 10444, 10443
VIEWPIA	10730, 10641
VISION	10249, 10108
VISIONMAGIC	10187
VOG	10069
VOXSON	10204
WALKER	10286
WALTHAM	10171
WATSON	10293, 10264, 10249, 10194, 10171, 10127, 10108, 10074, 10064
WATT RADIO	10185
WEGAVOX	10282, 10264, 10249
WELLTECH	10250
WELTBlick	10110, 10108
WHARFEDALE	10524, 10313
WHITE WESTINGHOUSE	10260, 10110, 10108
WIEWPIA	10427
WILSON	10569, 10249
WINSON	10250
WORTEN	10273, 10229, 10120, 10110
XENIUS	10298
XIRON	10731,10303
YAMO	10064
YOKO	10274, 10171, 10170, 10164, 10108, 10064
ZANELA	10224
ZANUSSI	10197